

nVent Enlogic PCT

Version 3.0.8

User Guide

Document Version – 1.2




Table of Contents

Table of Contents.....	2
1. GETTING STARTED	4
2. PCT USER INTERFACE.....	6
3. New SKU Configuration File Creation.....	7
4. Input Settings.....	11
5. Firmware Flashing Tool.....	12
6. Phase Voltage Settings	19
7. Phase Current Settings.....	21
8. Phase Power	22
9. Outlets.....	23
10. Circuit Breakers	24
11. Data Log Settings.....	25
12. SNMP Settings.....	26
13. Trap Settings.....	28
14. Date/Time Settings	29
15. Email Setup	30
16. Event Notification.....	31
17. Network Settings	32
18. User Management.....	35
19. System Settings.....	38
20. Rack Access Control.....	39
21. Smart Rack Access	40
22. Network Services.....	43
23. Save.....	44
24. Help	45

DISCLAIMER

1. **Enlogic by nVent** accepts no liability for any errors in this documentation. To the maximum extent permissible by law, any liability for damage, direct or indirect, arising from the supply or use of this documentation is excluded.
2. **Enlogic by nVent** retains the right to modify this document, including the liability disclaimer, at any time without notice and accepts no liability for any consequences of such alterations.


1. GETTING STARTED

1.1 SCOPE


The document is a detailed user guide to utilize the PCT tool to configure Enlogic PDUs.

1.2 Download the PCT tool

1. Log in to www.enlogic.com
2. Click on the “**RESOURCES & SUPPORT**” tab on the home page.
3. In the Firmware/Software section, select and click the **PCT (PDU Config Tool) download** option in the of the dropdown.




4. The **Firmware/Software** page will be displayed, here scroll down to the latest version of the **PCT_Setup.msi** file to download.




1.3 Installing the PCT tool


1. In the Downloads folder, double-click on the **PCT_Setup.msi**.
2. Click on the **“Next”** option to proceed the **“Finish”** and the tool will be installed.



3. On the desktop, double-click on the **Enlogic by nVent** thumbnail to open the tool.



2. PCT USER INTERFACE



PCT Home Page

1. The Enlogic PCT Home page is displayed. The **New SKU** Icon is highlight on this page.
2. The top blue ribbon displays the latest version of the tool. Use the **Home** icon at any time to return to the Home page.

Notes –

Before working with PCT consider checking the following:

1. The SNMP with IP 0.0.0.0 or the system IP (on which the tool is installed) should be enabled. Putting the PDU to default will enable the IP (0.0.0.0).
2. Enable SSH with default port 22.
3. Enable FTPS with default port 21.
4. Enable TELNET with default port 23.
5. To activate most of the icons on the Home screen, the first step is to set the SKU.
6. SKUs can be configured by two methods.
 - a. Option 1 - User can select the SKU from the available SKU list OR
 - b. Option 2 - User can upload SKU configuration file from a stored location for any new SKUs and add them to the SKU Bin.
7. Before uploading the configuration “config.ini” file from the PCT tool, the PDU should be always in default settings.



3. New SKU Configuration File Creation

SKUs can be configured by two methods:

1. **Option 1** - User can select the SKU from the available SKU file OR
2. **Option 2** - User can upload SKU configuration file from a stored location for any new SKUs and add them to the SKU Bin.


Option 1


1. On the **Home page**, click on the **New SKU** Icon.
2. The New Configuration screen will be displayed. Under the **SKU Numbers** dropdown menu, select the SKU from the list and click on **Create Configuration** button. This will load the SKU to the PDU and display the SKU# on the top left corner.



Option 2


1. Select the SKU.bin to create the conf.ini file.
2. Ensure the SKU.bin file is placed in a local computer location.






Name	Date modified	Type	Size
conf.ini	12/19/2024 10:11 AM	Configuration settings	46 KB
dconf.ini	12/19/2024 10:26 AM	Configuration settings	46 KB
ipeth0.cfg	12/19/2024 10:11 AM	Configuration Source File	1 KB
ipeth1.cfg	12/19/2024 10:11 AM	Configuration Source File	1 KB


2. Select the file and click **Open**. The Configuration file is created successfully.



3. Under the **SKU Numbers** dropdown menu, select the SKU from the list and click on **Create Configuration** button.




1. If the user selects a wrong configuration file, then the application exits. The user will need to restart the configuration process with the correct file.
2. After the SKU is selected, all the PDU settings are enabled. Select each option, edit the settings, and click on the back button.
3. Clicking on the **Back** button will auto save the settings.




Note : Click **SAVE** icon at all times to save all the changes and create a config.ini file.

To save changes for each step, the user clicks on the  button.


If the user clicks on the Home button to navigate to other pages, there is no auto-save option for automatically saving the settings/changes.



4. Input Settings



1. Click on the **Input Settings** icon to set the Power Threshold, PDU RCM Thresholds, Overload Prevention Threshold, Outlet settings, Power Share Settings, and RCM Self Test Schedule.
2. The mouse-over tool tip indicates the range power values as per the SKU DA drawings. Input the Low and High Power Threshold settings priority wise.
3. The user can enable/disable Power Share feature. [refer the Enlogic User manual on the www.enlogic.com website for details on Power Share]
4. The user can specify the Overload Threshold percentage and reset timer.
5. If the SKU is equipped and embedded with an Residual Current Monitoring (RCM) Module, the user can specify a RCM Self Test Schedule.
6. The mouse-over tool tip indicates the outlet  values. Input the values and click on the  button to save changes.



Power Threshold Settings

Low Critical (W)	0	<input type="checkbox"/>
Low Warning (W)	0	<input type="checkbox"/>
High Warning (W)	0	<input type="checkbox"/>
High Critical (W)	0	<input type="checkbox"/>
Reset Threshold (W)	0	<input type="checkbox"/>
Alarm State Change Delay (Samples)	0	

PDU RCM Thresholds

High Warning (mA)	15	<input checked="" type="checkbox"/>
High Critical (mA)	20	<input checked="" type="checkbox"/>
Reset Threshold (mA)	1	
Alarm State Change Delay (Samples)	1	

Overload Prevention Threshold (VA)

Enable	<input type="checkbox"/>
Overload Threshold	5%
Reset Timer	30 mins
Load Rating (VA)	1

Outlet Settings

Outlet State On PDU Startup	On
Outlet On Delay (0 ~ 7200 sec)	0
Outlet Off Delay (0 ~ 7200 sec)	0
Outlet Reboot Duration (5 ~ 60 sec)	5
Device Detect Threshold (50 - 150)	150

Power Share Settings

PowerShare Enable	<input checked="" type="checkbox"/>
-------------------	-------------------------------------


RCM Self Test Schedule


Enable	<input type="checkbox"/>
Frequency	Monthly
Date/Time	17/12/2024 09:48:05
Day Of The Week	Tuesday
Start Time (HH:MM:SS)	9 : 48 : 5

5. Firmware Flashing Tool




1. Click on the Tools icon to upload the Firmware.
2. Enter a valid IP address xxx.xxx.xxx.xxx, E.g.: 10.10.105.174 and select the Scan Type as **PDU Only** or **All Pingable IPs** . Click on **Scan** to check for the IPs in the network.
3. If **PDU Only** is selected the result will display a list of all Enlogic PDU IPs in the network with the default username and password.







4. The default username and password displayed will be 'admin' and '12345678' .
5. You can change it to any valid username of 'admin' privilege to upload the firmware/ configuration file.
6. From the IP addresses list, select the IPs to upload the firmware. Click on **Browse Firmware or Configuration File** button.
7. Enter the current password of the PDU in the **Password** field.
8. Edit the PDUs username and password before uploading the firmware file. It will show default username and password. To edit it click on the username and password field and edit it.



9. If **All Pingable IPs** is selected the result will display a list of all IPs in the network with the default username and password.




10. If the user needs to list all pingable Enlogic IPs, the IP search can be set with a range xxx.xxx.xxx.xxx-xxx For e.g.: 10.10.105.40-255 . Click Scan. All the total IPs will be displayed.



11. Click on the **Save IP Address** button to save the IP addresses in an excel sheet at the selected location.

12. Click on **Import IP Address** button to import the IP addresses previously stored in an excel sheet.



13. To delete IPs which do not need a firmware upload, select them from the and click on the '-' button.
14. If you want to add any entry, then click on the '+' button. An empty field will appear, add a new IP, username, and password.
15. Select the field to be edited and click the **pen** button to make changes.
16. Select the **tick** symbol to end any edit.
17. Select the '**x**' **close** symbol is to complete an edit.
18. Click on the  button to save changes.

Upload Firmware or Configuration for individual IPs

Typically an IP scan, will return with multiple IPs, even though when selected only one IP is highlighted. But when you initiate the firmware/ conf file upload, it will apply to all the IPs in the list.

If you want to upload firmware or conf.ini file on only one IP, then follow the steps below:


1. If your IP is in the list, then remove all IPs by selecting it and removing it using the '-' button.
2. Skip IP scan, Click the '+' button to add a new field and enter the PDU details (IP, username, and password).

Specific IPs can be listed with a scan range. The scan will list out specific IPs with the default username and password.


Note - PDUs with default passwords – For default PDUs enter the default password in the **Password** field. The PDU will get set back to the current password (i.e., 12345678) during Configuration/Firmware Upload.

3. Select scanned IP and the firmware file or the configuration file that you want to upload and click on the **Browse Firmware or Configuration File** button.
4. Select the conf.ini file from the folder. Click **Flash Firmware** button to upload.

Note: PCT tool will upload the configuration file on the master and all the slave PDUs connected.




5. The Upload Status section will provide the information. If upload is successful, the PDU will reboot.




6. Click on **Clear Result** button to clear all the IP entries.
7. Click on the **Yes** button to confirm and delete all the entries.
8. Click  on the button to save changes.

6. Phase Voltage Settings




1. Click on the **Phase Voltage** icon to set the values in the input Phase Voltage settings page.
2. On a mouse-over you can check the voltage range to be set for each tab. If you have selected a **Single Phase SKU**, enter the Low Critical voltage to High Critical Values for one phase, update the threshold and alarms settings.
3. Click on the button  to save changes.

Single Phase SKU



Three Phase SKU

1. Click on the **Phase Voltage** icon to set the values.
2. On a mouse-over you can check the voltage range to be set for each tab. If you have selected a **Three Phase SKU**, enter the Low Critical voltage to High Critical Values for all three phases, update the threshold and alarms settings.
3. Click on the  button to save changes.




The screenshot shows the 'Phase Voltage' configuration window in the PDU Configuration Tool. The window title is 'PDU Configuration Tool' with a home icon. The main title is 'Phase Voltage' with a back arrow icon. The configuration is organized into a table with columns for different voltage thresholds and delay settings. Each cell contains a numerical value and a checkmark.

Phase	Low Critical (V)	Low Warning (V)	High Warning (V)	High Critical (V)	Reset Threshold	Alarm State Change Delay
Phase 1	180 ✓	190 ✓	250 ✓	250 ✓	2	0
Phase 2	180 ✓	190 ✓	250 ✓	250 ✓	2	0
Phase 3	180 ✓	190 ✓	250 ✓	250 ✓	2	0

7. Phase Current Settings




1. Click on the **Phase Current** icon to set the values in the input Phase Current settings page.
2. On a mouse-over you can check the current range to be set for each tab. If you have selected a **Three Phase SKU**, enter the Low Critical amperage values to High Critical amperage values for three phases, update the threshold and alarms settings.
3. Click on the button  to save changes.




Phase	Low Critical (A)	Low Warning (A)	High Warning (A)	High Critical (A)	Reset Threshold	Alarm State Change Delay
Phase 1	0	0	45	57	1	0
Phase 2	0	Please enter value between 0 - 63	45	57	1	0
Phase 3	0		45	57	1	0


8. Phase Power



1. Click on the **Phase Power** icon to set the values for Active and Apparent Phase Power threshold settings.
2. On a mouse-over you can check the power range to be set for each tab. Enter the Low Critical amperage values to High Critical amperage values and update the threshold and alarms settings.
3. Click on the button  to save changes.



9. Outlets



1. Click on the **Outlet** icon to configure threshold settings on the Control Outlets page.
2. On a mouse-over you can check the wattage range to be set for each tab. The values need to be set for the Outlets in a priority sequence. If there is an errored value entered, it will be indicated in a red colour icon against the Outlet# selected.
3. Click on the button to save changes.

PDU Configuration Tool


Control Outlets

Drag a column header here to group by that column

Outlet Name	Low Critical (W)	Low Warning (W)	High Warning (W)	High Critical (W)	Reset Threshold	Change Delay (W)
OUTLET1	0	5000	0	0	0	0
OUTLET2	0		0	0	0	0
OUTLET3	0		0	0	0	0
OUTLET4	0	0	0	0	0	0
OUTLET5	0	0	0	0	0	0
OUTLET6	0	0	0	0	0	0
OUTLET7	0	0	0	0	0	0
OUTLET8	0	0	0	0	0	0
OUTLET9	0	0	0	0	0	0
OUTLET10	0	0	0	0	0	0
OUTLET11	0	0	0	0	0	0
OUTLET12	0	0	0	0	0	0
OUTLET13	0	0	0	0	0	0
OUTLET14	0	0	0	0	0	0
OUTLET15	0	0	0	0	0	0
OUTLET16	0	0	0	0	0	0
OUTLET17	0	0	0	0	0	0
OUTLET18	0	0	0	0	0	0
OUTLET19	0	0	0	0	0	0
OUTLET20	0	0	0	0	0	0
OUTLET21	0	0	0	0	0	0
OUTLET22	0	0	0	0	0	0
OUTLET23	0	0	0	0	0	0
OUTLET24	0	0	0	0	0	0
OUTLET25	0	0	0	0	0	0
OUTLET26	0	0	0	0	0	0
OUTLET27	0	0	0	0	0	0
OUTLET28	0	0	0	0	0	0
OUTLET29	0	0	0	0	0	0
OUTLET30	0	0	0	0	0	0
OUTLET31	0	0	0	0	0	0
OUTLET32	0	0	0	0	0	0
OUTLET33	0	0	0	0	0	0
OUTLET34	0	0	0	0	0	0
OUTLET35	0	0	0	0	0	0

Please enter value between 0 - 4160

10. Circuit Breakers



1. Click on the **Circuit Breakers** icon to configure threshold settings on the circuit breaker settings page.
2. On a mouse-over you can check the amperage range to be set for each tab. In this section, enter the Low Critical amperage values to High Critical amperage values for circuit breakers, update the threshold and alarms settings.
3. Click on the button  to save changes.

PDH Configuration Tool v3.0.8


Circuit Breaker Settings

Drag a column header here to group by that column

Breaker Name	Low Critical (W)	Low Warning (W)	High Warning (W)	High Critical (W)	Reset Threshold	Change Delay (W)
B1	0	0	14	15	1	0
B2	0	0	14	15	1	0
B3	0	0	14	15	1	0
B4	0	0	14	15	1	0
B5	0	0	14	15	1	0
B6	0	0	14	15	1	0
B7	0	0	14	15	1	0
B8	0	0	14	15	1	0
B9	0	0	14	15	1	0
B10	0	0	14	15	1	0
B11	0	0	14	15	1	0
B12	0	0	14	15	1	0
B13	0	0	14	15	1	0
B14	0	0	14	15	1	0
B15	0	0	14	15	1	0
B16	0	0	14	15	1	0
B17	0	0	14	15	1	0
B18	0	0	14	15	1	0
B19	0	0	14	15	1	0
B20	0	0	14	15	1	0
B21	0	0	14	15	1	0
B22	0	0	14	15	1	0
B23	0	0	14	15	1	0
B24	0	0	14	15	1	0

Record 24 of 24

11. Data Log Settings



1. Click on the **Logs** icon to configure Data Log Settings and the Syslog Configuration on this page.
2. For Data Log Settings, on a mouse-over you will be given a hint to add the Log interval duration to be set in Minutes. Add the duration and click on Enable.
3. For Syslog Configuration, on a mouse-over you will be given a hint to add the IPV4 IP address, server port number and select Syslog Protocol [UDP/TCP/UDP+TCP]. Toggle on to **Enable**.
4. Add the Syslog settings – security mapping and facilities.
5. Click on the  button to save changes.

Data Log Settings

Log Interval (1 - 1440 min) 10

Enable Data Logging

Syslog Configuration

Syslog Server Address

Syslog Server Port 514

Syslog Protocol UDP

Enable Syslog Server Access

Syslog Setting


Facility Local0

Severity Mapping Critical Critical



Severity Mapping Warning Warning

Severity Mapping Informational Informational


12. SNMP Settings




1. Click on the **SNMP/Trap Settings** icon to configure settings for SNMP Manager.
2. Access the first tab, **General** and enable the SNMP Manager, enter the version, port, and trap port settings.




- Access the second tab, **SNMP Manager**, add the settings for the V1/2c Manager IP Address and enable it. The user can add up to five IP addresses and enable them.



- In the **SNMP Manager** page, add the settings for the V3Manager User Name, Security Level, Auth Password, Algorithm, Privacy Key and Algorithm and enable it. The user can add up to five User Names and enable them.



13. Trap Settings



1. Click on the **SNMP/Trap Settings** icon to configure settings for Trap Receivers.
2. Access the third tab, **Trap Receiver** and enable V1/2c Trap Name, other settings and enable it.
3. In the same page, the second table set the V3 Trap Name, other settings and enable it.
4. Click on the  button to save changes.

The screenshot displays the 'SNMP Manager/Trap Receivers' configuration page in the PDU Configuration Tool. It is divided into two main sections: V1/2c Trap Receivers and V3 Trap Receivers.

V1/2c Trap Receivers Table:

V1/2c Trap Name	Host	Community	Enable/Disable
		public	<input type="checkbox"/>

V3 Trap Receivers Table:

V3 Trap Name	Host	Security Level	Auth Password	Auth Algorithm	Privacy Key	Privacy Algorithm	Enable/Disable
		No Auth No Priv		MDS		DES	<input type="checkbox"/>
		No Auth No Priv		MDS		DES	<input type="checkbox"/>
		No Auth No Priv		MDS		DES	<input type="checkbox"/>
		No Auth No Priv		MDS		DES	<input type="checkbox"/>
		No Auth No Priv		MDS		DES	<input type="checkbox"/>

The bottom screenshot shows the configuration after data entry:


V1/2c Trap Receivers Table:

V1/2c Trap Name	Host	Community	Enable/Disable
User Tuscon	10.10.105.126	public	<input checked="" type="checkbox"/>
User Wuxi	10.10.105.174	public	<input checked="" type="checkbox"/>
		public	<input type="checkbox"/>
		public	<input type="checkbox"/>
		public	<input type="checkbox"/>



V3 Trap Receivers Table:

V3 Trap Name	Host	Security Level	Auth Password	Auth Algorithm	Privacy Key	Privacy Algorithm	Enable/Disable
Manager	10.10.105.126	Auth Priv	manager123	MDS	123484	YES	<input type="checkbox"/>
Superadmin	10.10.105.174	No Auth No Priv		MDS		DES	<input type="checkbox"/>
		No Auth No Priv		MDS		AES128	<input type="checkbox"/>
		No Auth No Priv		MDS		AES192	<input type="checkbox"/>
		No Auth No Priv		MDS		AES256	<input type="checkbox"/>


14. Date/Time Settings




1. Click on the **Date** icon to configure Date/Time Settings on the page.
2. Select the Date/Time zone from the dropdown menu
3. In the Network Time Protocol (NTP) table, click Enable and add the NTP primary, secondary server IPs and select the GMT offset time zones from the dropdown menu.
4. In the Daylight Saving Time (DST) table, click Enable and add all day light saving settings.
5. Click on the  button to save changes.




15. Email Setup




1. Click on the **Emails** icon to configure email settings on the page.
2. In the SMTP Account settings table, enter all the Email Server address and all other details to configure your email.
3. In the Email Recipients table, add the email ids and select to enable them.
4. Click on the button  to save changes.




16. Event Notification




1. Click on the **Event Notification** icon to enable the Email, SNMP Trap and Syslog settings for various events on this page. Select each of the events and enable the required notifications.
2. Click on the button  to save changes.



17. Network Settings





1. Click on the **Network Settings** icon to enable the
 - Ethernet -1 IP configuration
 - Ethernet -2 IP Configuration
 - Web/RESTapi Access Configuration
 - SSH/FTPS Configuration
 - Certificate Key/Link Speed Configuration
 - Domain Name System
2. Click on the button  to save changes.
3. Enter the Ethernet -1 IP configuration settings.



The screenshot shows the 'Network Settings' window in the PDU Configuration Tool. The interface is divided into several sections for configuring network parameters:

- Ethernet-1 IP Configuration:** Network Mode (IPv4/IPv6 Dual), Boot Mode (DHCP), Boot Mode (IPv6) (Autoconfig), IPv4 Address (192.168.0.1), Network Mask (255.255.255.0), Default Gateway (192.168.0.1), IPv6 Address (2001:1200:1100:1000:98), Subnet Prefix Length (64), Default Gateway (IPv6) (2001:1200:1100:1000:1), LLDP (checked).
- Ethernet-2 IP Configuration:** Network Mode (IPv4/IPv6 Dual), Boot Mode (DHCP), Boot Mode (IPv6) (Autoconfig), IPv4 Address (192.168.0.1), Network Mask (255.255.255.0), Default Gateway (192.168.0.1), IPv6 Address (2001:1200:1100:1000:99), Subnet Prefix Length (64), Default Gateway (IPv6) (2001:1200:1100:1000:2), LLDP (checked).
- Web/ RESTapi Access Configuration:** Web Access (Https), Http Port (80), Https Port (443), Redirection (unchecked), REST API Access (Disable).
- Certificate Key/Link Speed Configuration:** SSL Certificate Key Length (2048 Bits), Ethernet Link Speed (Auto Negotiation).
- SSH/FTPS Configuration:** SSH Enable (checked), SSH Port (22), FTPS Access (checked), FTPS Port (21), Telnet Access (unchecked), Telnet Port (23).
- Domain Name System:** Manually Override Server (unchecked), Primary DNS Server (0.0.0.0), Secondary DNS Server (0.0.0.0).

4. Enter the Ethernet -2 IP Configuration settings.



5. Enter the Web/RESTapi Access Configuration settings.
6. Enter SSH/FTPS/TELNET Configurations, Certificate Key/Link Speed Configuration and Domain Name System settings.

Network Settings

Ethernet-1 IP Configuration

Network Mode	IPv4/IPv6 Dual
Boot Mode	DHCP
Boot Mode (IPv6)	STATIC
IPv4 Address	192.168.0.1
Network Mask	255.255.255.0
Default Gateway	192.168.0.1
IPv6 Address	2001:1200:1100:1000::98
Subnet Prefix Length	64
Default Gateway (IPv6)	2001:1200:1100:1000::1
LLDP	<input type="checkbox"/>

Ethernet-2 IP Configuration

Network Mode	IPv4/IPv6 Dual
Boot Mode	Static
Boot Mode (IPv6)	Autoconfig
IPv4 Address	192.168.0.1
Network Mask	255.255.255.0
Default Gateway	192.168.0.1
IPv6 Address	2001:1200:1100:1000::99
Subnet Prefix Length	64
Default Gateway (IPv6)	2001:1200:1100:1000::2
LLDP	<input checked="" type="checkbox"/>

Web/ RESTapi Access Configuration

Web Access	Http & Https
Http Port	80
Https Port	443
Redirection	<input type="checkbox"/>
REST API Access	Disable

Certificate Key/Link Speed Configuration

SSL Certificate Key Length	2048 Bits
Ethernet Link Speed	Auto Negotiation


SSH/FTPS Configuration

SSH Enable	<input checked="" type="checkbox"/>
SSH Port	22
FTPS Access	<input checked="" type="checkbox"/>
FTPS Port	21
Telnet Access	<input checked="" type="checkbox"/>
Telnet Port	23

Domain Name System

Manually Override Server	<input type="checkbox"/>
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0

18. User Management



1. Click on the **User Management** icon to enable the User, Roles, LDAP settings, Session Management, Password Policies and Radius server configurations on this page. Select each of the tabs and enable the settings.
2. Click on the button  to save changes.

User

1. Access the first tab, **Add User** and add new users with roles admin, manager, and user.
2. The user is expected to enable/disable **Force Password change** at the time of Web UI login.
3. If **Force Password Change** is Enabled for a user, the PDU will prompt for password change after the configuration file is uploaded for that user.
4. If **Force Password Change** is Disabled, PDU will just login with the current user and will not request password change.


A screenshot of the PDU Configuration Tool's "User Settings" interface. The window title is "PDU Configuration Tool". The main header is "User Settings" with a green refresh icon. Below the header are several tabs: "Add Users", "Add Roles", "LDAP Settings", "Session Management", "Password Policies", and "Radius Configuration". The "Add Users" tab is active. On the left, there is a form for adding a user with fields for "Username", "Password", "Confirm Password", and "User Role" (set to "Admin"). There is a checkbox for "Force Password Change during login" which is checked. At the bottom of the form are "Add User" and "Clear" buttons. On the right, there is a table with the following data:

#	Username	Password	Role	Force Pwd Change
1	admin	*****	admin	✓
2	user	*****	user	✓
3	manager	*****	manager	✓

At the bottom of the window, there is a status bar showing "Record 3 of 3" and some navigation icons.


Role

5. Access the second tab, **Add Role**, and add/modify roles for different users.




LDAP/LDAPS Settings

6. Access the third tab, enable the **LDAP** server details.




Session Management

7. Access the fourth tab, enable the **Sessions** settings.




Password Policies

8. Access the fifth tab, update the **Password** policies, and enable the required rules.




Radius Configuration

9. Access the sixth tab, update the **Radius** configurations, and enable the settings.



19. System Settings



1. Click on the **System Settings** icon to enable the System Information, Power Panel Core Location and Rack location configurations on this page.
2. Enter details under each table to enable the system settings.
3. Click on the button  to save changes.

The screenshot shows the "PDU Configuration Tool" window with a blue title bar. The main content area is dark blue and titled "System Management". It contains three configuration panels:

- System Information:** Fields for System Name, Contact Name, Contact Email, Contact Phone, and Contact Location. A dropdown for LED Edge Color is set to "Blue", and a dropdown for OLED Rotate is set to "0°".
- Power Panel_Core Location:** Fields for Power Panel Name, Core Location (dropdown set to "Front"), and Core U Position (set to "0").
- Rack Location:** Fields for Room Name, Row Name, Row Position, Rack Name, Rack ID (set to "0"), and Rack Height (set to "0").

20. Rack Access Control




1. Click on the **Rack Access Control** icon to add multiple Cards and details of each one of them on this page.
2. Multiple Cards can be managed using the add/delete/edit options.
3. Click on the button  to save changes.

The screenshot shows the "Rack Access Control" interface within the "PDU Configuration Tool v3.0.3". The interface is dark-themed and contains the following elements:

- Add Card Information:** A form on the left with three input fields: "Card ID", "Card User", and "Card Aisle". Below these fields are two buttons: "Add Card" and "Clear".
- Table:** A table on the right with the following columns: "#", "Card ID", "Card User", "Card Aisle", and "Created On". The table is currently empty.
- Footer:** At the bottom right, there is a status bar showing "Record 2 of 2" and several navigation icons.


21. Smart Rack Access



1. Click on the **Smart Rack Access** icon to add Cards, Rack Access, Handle, Keypad, Beacon and LED settings and configurations on this page.
2. Select each of the tabs and enable the settings.
3. Click on the button  to save changes


Cards

1. Access the first tab, **Add Cards** and add card details. Multiple cards can be added using this page.




Rack Access Settings

2. Access the second tab, **Add Rack Access** and add the settings.




Rack Access Settings

3. Access the third tab, **Handle Settings** and add the settings.




Keypad Settings

4. Access the fourth tab, **Keypad Settings** and enable the settings.




Beacon Settings

5. Access the fourth tab, **Beacon Settings** and enable the settings.



LED Settings


6. Access the fifth tab, **LED Settings** and enable the settings.



22. Network Services




1. Click on the **Network Services** icon to enter the start IPv4 and end IPv4 for Ethernet-1 and Ethernet-2 IP addresses with the accurate Network mask and Default gateway configurations on this page.
2. Click on the button  to save changes



To upload the conf.ini file on multiple PDUs with ipeth1.cfg and ipeth2.cfg follow the below steps:


1. In Network Settings, enter the Eth1 and Eth2 IPv4 addresses with accurate Network mask and Default gateway and set it to **Static** mode.
2. In **Network Services** page, enter the start IP and end IP for Ethernet-1 and Ethernet-2 IP addresses with the accurate Network mask and Default gateway.
3. Save the conf.ini file.
4. Four files will be saved:
 - conf.ini
 - deconf.ini (this file can be ignored)
 - ipeth0.cfg
 - ipeth1.cfg
5. Copy the three files - conf.ini, ipeth0.cfg and ipeth1.cfg into the USB and **upload the conf file through OLED menu -> Setup -> USB -> UPLOAD CONFIG.**
6. After upload, the eth0 and eth1 IP will be assigned to the start IPs of eth1 and eth2
7. Now, upload to different PDU and the IP of Eth1 and Eth2 should be incremented.

23. Save




1. Click on the **Save** icon to save all the settings and changes made and create a config.ini file.
2. Select the location to save the SKU settings and click **OK** to save.
3. To save changes for each step, the user clicks on the  button.
4. If the user clicks on the Home button to navigate to other pages, there is no auto-save option for automatically saving the settings/changes.

24. Help



1. Click on the **Help** icon to navigate to the Enlogic website page.



MANUFACTURED BY
Enlogic

Our powerful portfolio of brands:

CADDY

ERICO

HOFFMAN

ILSCO

RAYCHEM

SCHROFF



©2024 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners. nVent reserves the right to change specifications without notice.

nVent-OM-N01833-EnlogicAdvantageSecure-EN-2406

[nVent.com](https://www.nvent.com)