

用于安装 PCB 的 INTERSCALE 灵活轨道系统

Interscale 灵活型轨道组件，用于在 Interscale SFF 机箱中安装 PCB。结合安装板，支持单独安装 PCB

功能

单板支架用螺栓固定在安装板上

PCB (board thickness 1.4 ... 2.6 mm) can be positioned flexibly

SPECIFICATIONS

Table 1/2

物料号	包装数量	产品类型	产品系列	搭配使用	类型	材料
24827-025	2	安装五金包	Interscale	小尺寸机箱	安装五金包	铝
24827-027	2	安装五金包	Interscale	小尺寸机箱	安装五金包	铝
24827-023	2	安装五金包	Interscale	小尺寸机箱	安装五金包	铝
24827-024	2	安装五金包	Interscale	小尺寸机箱	安装五金包	铝

Table 2/2

物料号	长度
24827-025	217.45 mm
24827-027	306.35 mm
24827-023	128.55 mm
24827-024	173 mm

警告

应仅根据 nVent 的产品说明书与培训材料安装并使用 nVent 的产品。可访问 www.nvent.com 获取说明书，或者向您的 nVent 客服代表索取。错误安装、使用不当、滥用或未能完全遵守 nVent 的说明与警告，可能会造成产品故障、财产损失、严重的人身伤害及死亡和/或使得保修服务无效。



Our powerful portfolio of brands:
[nVent.com](https://www.nVent.com) CADDY ERICO HOFFMAN RAYCHEM SCHROFF TRACER

© 2025 nVent. All nVent marks and logos are owned or licensed by nVent Services GmbH or its affiliates. All other trademarks are the property of their respective owners.

nVent reserves the right to change specifications without notice.