

# 19" ASSEMBLY KIT M6



For standard grounding use a grounding nut and washer on at least one attachment point.

When 19" assembly kit is used with conductive 19" panel mount, grounding cage nuts are not needed.

## CERTIFICATIONS



## FEATURES

- Assembly kits for assembly of 19" components into a cabinet
- For mounting of front panels, distribution fields or other components on the frame, slide mounts or depth members with square cut-outs

## SPECIFICATIONS

Table 1/2						
Catalog Number	Type	Accessory Type	Product Type	Works With	Package Quantity	Finish
21100-435	Mounting Kit	Mounting hardware	Assembly Kit	19" Cases, 19" Wallmount, 19" Indoor Cabinets, 19" Outdoor Cabinets	8	Zinc Plated
21101-809	Mounting Kit	Mounting hardware	Assembly Kit	19" Cases, 19" Wallmount, 19" Indoor Cabinets, 19" Outdoor Cabinets	50	Zinc Plated

Catalog Number	Type	Accessory Type	ProductType	Works With	Package Quantity	Finish
21101-810	Mounting Kit	Mounting hardware	Assembly Kit	19" Cases, 19" Wallmount, 19" Indoor Cabinets, 19" Outdoor Cabinets	100	Zinc Plated

Table 2/2

Catalog Number	Material	Thread Size
21100-435	Steel, ABS	M6
21101-809	Steel, ABS	M6
21101-810	Steel, ABS	M6

**WARNING**

nVent products shall be installed and used only as indicated in nVent's product instruction sheets and training materials. Instruction sheets are available at [www.nvent.com](http://www.nvent.com) and from your nVent customer service representative. Improper installation, misuse, misapplication or other failure to completely follow nVent's instructions and warnings may cause product malfunction, property damage, serious bodily injury and death and/or void your warranty.



Our powerful portfolio of brands:  
**nVent.com CADDY ERICO HOFFMAN RAYCHEM SCHROFF**  
**TRACER**